





Инструкция по установке


KR-75






1		X1
2		X1
3		X1
4	 $\phi 8$	X5
5	  ST4X35	X5
6	  ST4X10	X3
7	  ST4X30	X3
8		X3
9		X1
10		X2
11		X2





12		X1
13		X1
14		X1
15		X1

		
 $\phi 8$ $\phi 3.2$		
		




A




D




E




F



G



H



I

